

Clean Steam Traps LV6 Series ss3-P/SS5-P



Designed for Bio and Clean Steam Applications

Clean Steam Trap

All Stainless Steel Construction

■ Low-quality stainless steel may corrode when exposed to water with even low ionic content. To solve this problem, the LV6 series uses AISI316L, and the SS3-P/SS5-P body and cover are made of A351 Gr. CF3M with an SUS316L float.

Prevents Condensate Accumulation

- Smooth, virtually crevice-free interior allows for complete condensate drainage.
- The SS3-P/SS5-P has a small drain hole to prevent condensate pooling.









- Consists of only 5 simple components held together by easily removable clamps.
- Clamp pipe connections enable the trap to be easily removed from the pipeline.

Prevents Bacterial Contamination



LV6 Series

- Simply constructed clamp has few projections.
- Sanitary highperformance fluorine resin gasket complies with FDA 21 CFR 177, USP Class VI and EN 1935.



■ Ferrule clamp joint for clean steam, in accordance with ISO and ASME-BPE (Tri-Clamp compatible) standards, is used for connection to piping. Tube end connections are also available.



- Uniquely designed free-draining X-element* case with large openings allows for complete fluid drainage and easy cleaning. It is electropolished for the LV6-P and the optional LV6-EP.
 - *LV6-CE is equipped with a standard X-element.



■ The SS3-P and SS5-P free floats have an internal 0.8µm Ra buff polish.

(The optional SS3-EP and SS5-EP have a $0.4\mu m$ Ra buff and electro-polish [internal and external])











Thermostatic Clean Steam Trap

Compact LV6 Series

What is the X-element?

■ A multi-diaphragm valve mechanism filled with a thermoliquid which opens and closes the valve at approximately 6°C less than saturated steam temperature.



Thermoliquid Diaphragm

Fail-open Safety Mechanism

■ In the event of a damaged diaphragm, the LV6 is not blocked, but remains open, ensuring the operation of the steam using equipment.

Automatic Air Venting

- The LV6 rapidly vents low temperature air and condensate at system start up, therefore reducing overall start-up time and improving productivity.
- In addition to rapid air venting at start up, air at near-to-steam temperature can be almost completely vented during operation, making the LV6 suitable for batch processes.



Free Float Clean Steam Trap Continuous Discharge SS3-P/SS5-P

Continuous Discharge of Condensate

■ The self-modulating free float automatically adjusts to the level of condensate allowing continuous discharge. There is no condensate backup or accumulation in the equipment.



High Durability and Long Life

■ The free float with simple construction and only one moving part, without levers or hinges, has less failure. Valve wear is distributed across the entire float surface, greatly improving valve service life.

Suitable for Condensate Recovery

■ Even with a back pressure of 99% of operating steam pressure, the free float operates without fail. The SS3-P and SS5-P are therefore suitable for condensate recovery in closed systems.



LV6 • Specifications Series



Model	LV6-CE	LV6-SF	LV6-P	LV6-EP*			
Material	Stainless Steel AISI316L (DIN1.4404)						
Connection	Clamp End** / Tube End***						
Size	DN 15, 20, 25 / DN 8, 10, 15, 20, 25						
Maximum Operating Pressure (barg) PMO	6						
Minimum Operating Pressure (barg)	0.1						
Maximum Back Pressure	90% of Inlet Pressure						
Maximum Operating Temperature (°C) TMO	165						
Maximum Discharge Capacity (kg/h)	770						
Subcooling of X-element Fill (°C)	Up to 6						
X-element type (for Clean Steam Traps)	Standard	Free-draining	Free-draining (E	Electro-polished)			
Clamp Type	2-piece Clamp (Buff-polished) 3-piece Clamp (Buff-polished						
Finishing (Internal/External)	Natural Machining	0.8 μm Ra / 1.2 μm Ra Fine Machining 0.8 μm Ra / 1.2 μm Ra Buff-polished		0.4µm Ra Electro-polished			

^{*} Option ** ISO 2852, ASME-BPE (Tri-Clamp compatible), other standards available.

1 bar = 0.1 MPa

*** ISO 1127, other standards available

PRESSURE SHELL DESIGN CONDITIONS (NOT OPERATING CONDITIONS): Maximum Allowable Pressure (barg) PMA:10 Maximum Allowable Temperature (°C) TMA: 185





Model		SS3-E*	SS3-P	SS3-EP*	SS5-P	SS5-EP*	
Material	Body: Cast Stainless Steel A351 Gr.CF3M (DIN 1.4435) Float: Stainless Steel SUS316L (DIN 1.4404)						
Connection		Clamp End**					
Size	DN 15, 20			DN 25, 38			
Maximum Operating Pressu	6						
Maximum Differential Press	6						
Maximum Operating Temp	165						
Maximum Discharge Capac	155			530			
Finishing***	Internal	25µmRa Electro-polished	0.8μm Ra Buff-polished	Buff-polished then 0.4 μ m Ra Electro-polished	0.8µm Ra Buff-polished	Buff-polished then 0.4 µm Ra Electro-polished	
	External		25µmRa Electro-polished		Bead blasted and Electro-polished		

^{*} Option ** ISO 2852, ASME-BPE (Tri-Clamp compatible) *** Treated base surfaces are lost-wax casted

PRESSURE SHELL DESIGN CONDITIONS (NOT OPERATING CONDITIONS): Maximum Allowable Pressure (barg) PMA:10 Maximum Allowable Temperature (°C) TMA:185



CAUTION To avoid abnormal operation, accidents or serious injury, DO NOT use this product outside of the specification range. Local regulations may restrict the use of this product to below the conditions quoted.

Full product details (sizes, pressures, capacities and materials, etc.) are included in the individual specification data sheets (SDS). Tri-Clamp is a registered trademark of Alfa Laval Corporate AB.

TLV Stainless Steel Product Series





























Contact **TLV** for more information on these and other stainless steel products.

TLY EURO ENGINEERING UK LTD.

Star Lodge, Montpellier Drive, Cheltenham, Gloucestershire, GL50 1TY, U.K. Tel: [44]-(0)1242-227223 Fax: [44]-(0)1242-223077 http://www.tlv.com



