

Serial No. H-V015-E-8

Stop valve

User's Manual






(1)	Be sure to read the following warranty
	clauses of our product 1
(2)	General operating instructions2
(3)	General instructions for transportation, unpacking and storage3
(4)	Name of parts 4
(5)	Maximum working pressure vs. temperature ————6
(6)	Installation procedure 7
(7)	Operating procedure 10
(8)	Disassembly and assembly procedure for parts replacement ————————————————————————————————————
(9)	Inspection items ————————————————————————————————————
(10)	Troubleshooting 12
(11)	Handling of residual and waste materials ————————————————————————————————————




(4) Name of parts

Nominal size,15mm~50mm (1/2"~2")









No.	Parts of name	
[1]	Body	
[2]	Bonnet	
[3]	Stem	
[4]	Grand	
[6]	Sheet gasket	
[7]	Grand packing	
[8]	Disc	
[9]	Stem holder	
[10]	Stem with trapezoid screw	
[11][21]	Bolt•nut	
[12][23]	Stud bolt • nut	
[13]	Support of stem	
[14]	Hand wheel	
[15]	Nut(A)	
[16]	Washer	
[20]	Inserted metal	
[23]	Lock nut	


Stop valve 5




(5) Maximum working pressure vs. temperature









Stop valve



(10) Troubleshooting

Problem	Problem Cause	
Fluid is leaking past the fully closed	Solid particles have lodged in the valve.	Clear the solid particles from the valve.
position.	The seat and disc are scratched.	Replace the seat and disk with new one.
The handle spins freely.	The stem is broken.	Disassemble bonnet and replace the stem.
The handle spins neery.	The stem holder is broken.	Disassemble bonnet and replace the stem.
Valve leaks between body and bonnet.	Bonnet bolts have loosened.	Re-tighten bolts & nuts.
valve leaks between body and bonnet.	Media has crystallized	Disassemble and clean on a regular basis.

(11) Handling of residual and waste materials



- Make sure to consult a waste treatment dealer for recommendations on the proper disposal of plastic valves. (Poisonous gas is generated when the valve is burned improperly.)

Stop valve 12



Stop valve

ASAHI YUKIZAI CORPORATION

<u>Distributor</u>		
		http://www.asahi-yukizai.co.jp/en/

Information in this manual is subject to change without notice.