# Victaulic<sup>®</sup> Series UTD Universal Test and Drain





## 1.0 PRODUCT DESCRIPTION

## **Available Sizes**

• 1 - 2"/DN25 - DN50

## **Pressure Class**

• Up to 300 psi/2068 kPa/21 Bar

## **Test Orifice K-Factor**

- 1"/DN25 K2.8 (4.0)
- 1<sup>1</sup>/<sub>4</sub>"/DN32 K4.2 (6.0)
- 2"/DN50 K5.6 (8.1)

## **Available Connections**

- 1"/DN25 NPT/IGS
- 1 1/4"/DN32 NPT/OGS
- 2"/DN50 NPT/OGS

## Ports

• (2) Integrated ports with clear Polycarbonate plugs, allowing for a visual indication water is flowing

## Standard:

• Preinstalled Series ARV (refer to <u>publication 30.75</u>) and plastic tubing.

## 2.0 CERTIFICATION/LISTINGS

c(ŲL)us <FM>

## 3.0 SPECIFICATIONS - MATERIAL

**3 Way Test and Drain Body:** Brass **UTD Test and Drain Ball:** Chrome-plated brass **UTD Test and Drain Handle Stem:** Stainless Steel

3-Way Test and Drain Stem O-Ring: EPDM

UTD Test and Drain Seal: PTFE

Sight Glass: Polycarbonate

3-Way Red Handle: EPDM


Retaining Nut: Stainless Steel


ALWAYS REFER TO ANY NOTIFICATIONS AT THE END OF THIS DOCUMENT REGARDING PRODUCT INSTALLATION, MAINTENANCE OR SUPPORT.

victaulic.com 30.73 15917 Rev A Updated 06/2021 © 2021 Victaulic Company. All rights reserved.



## 4.0 DIMENSIONS





Size		Dimensions					Weight
Nominal	Actual Outside Diameter	Α	В	с	D	E	Approximate (Each)
inches	inches	inches	inches	inches	inches	inches	lb
DN	mm	mm	mm	mm	mm	mm	kg
1	1.315	4.88	3.25	1.88	4.13	2.13	3.3
DN25	33.7	124	83	48	105	54	1.5
1 1⁄4	1.660	5.00	3.38	2.25	4.88	2.63	4.6
DN32	42.4	127	86	57	124	67	2.1
2	2.375	5.50	3.75	2.75	6.00	3.38	8.2
DN50	60.3	140	95	70	152	86	3.7

30.73 15917 Rev A Updated 06/2021 © 2021 Victaulic Company. All rights reserved.



## 5.0 PERFORMANCE

Si			
Nominal	Actual Outside Diameter	Maximum Working Pressure	
inches	inches	psi	
DN	mm	kPa	
1	1.315	300	
DN25	33.7	2068	
1 1⁄4	1.660	300	
DN32	42.4	2068	
2	2.375	300	
DN50	60.3	2068	

## 6.0 NOTIFICATIONS



- Read and understand all instructions before attempting to install, remove, adjust, or maintain any Victaulic piping products.
- Depressurize and drain the piping system before attempting to install, remove, adjust, or maintain any Victaulic piping products.
- Wear safety glasses, hardhat, and foot protection.

Failure to follow these instructions could result in death or serious personal injury and property damage.

## 7.0 REFERENCE MATERIALS

30.71: Series UM Universal Manifold Assembly

- 30.72: Series UMC Universal Manifold Control Assembly
- 10.54: FireLock<sup>™</sup> Innovative Groove System | IGS<sup>™</sup>
- 10.64: FireLock<sup>™</sup> Installation-Ready<sup>™</sup> Rigid Couplings Style 009N and Style 109

30.74: Series ARV Adjustable Relief Valve

### User Responsibility for Product Selection and Suitability

Each user bears final responsibility for making a determination as to the suitability of Victaulic products for a particular end-use application, in accordance with industry standards and project specifications, as well as Victaulic performance, maintenance, safety, and warning instructions. Nothing in this or any other document, nor any verbal recommendation, advice, or opinion from any Victaulic employee, shall be deemed to alter, vary, supersede, or waive any provision of Victaulic Company's standard conditions of sale, installation guide, or this disclaimer.

### Intellectual Property Rights

No statement contained herein concerning a possible or suggested use of any material, product, service, or design is intended, or should be constructed, to grant any license under any patent or other intellectual property right of Victaulic or any of its subsidiaries or affiliates covering such use or design, or as a recommendation for the use of such material, product, service, or design in the infringement of any patent or other intellectual property right. The terms "Patented" or "Patent Pending" refer to design or utility patents or patent applications for articles and/or methods of use in the United States and/or other countries.

#### Note

This product shall be manufactured by Victaulic or to Victaulic specifications. All products to be installed in accordance with current Victaulic installation/assembly instructions. Victaulic reserves the right to change product specifications, designs and standard equipment without notice and without incurring obligations.

### Installation

Reference should always be made to the Victaulic installation handbook or installation instructions of the product you are installing. Handbooks are included with each shipment of Victaulic products, providing complete installation and assembly data, and are available in PDF format on our website at www.victaulic.com.

### Warranty

Refer to the Warranty section of the current Price List or contact Victaulic for details. Trademarks

Victaulic and all other Victaulic marks are the trademarks or registered trademarks of Victaulic Company, and/or its affiliated entities, in the U.S. and/or other countries.

30.73 15917 Rev A Updated 06/2021 © 2021 Victaulic Company. All rights reserved.



