
2 WAYS NORMALLY CLOSED - DIRECT ACTING - G 1/8



## **General Features**

The flow rate is proportional to the input electric signal.

Suitable to shut off gaseous fluids (verify the compatibility of fluid with material in contact).

Overleaf we show one chart of flow rate/electric signal at 6 bar inlet pressure.

Technical Features				
Maximum allowable pressure (PS)	50 bar			
Fluid temperature	-10°C +140°C (EPDM) 0°C +130°C (FPM)			

Materials in Contact with Fluid			
Body	Brass		
Sealing	EPDM - FPM		
Internal components	Stainless steel		
Seat	Brass		
Guide assembly	Stainless Steel		

Coil		ZB10A	ZB12A			
Approval		/	UL and CSA			
Encapsulation	on material	PA fiberglass reinforced	PET fiberglass reinforced			
Insulation cla	ass	F (155°C)				
Ambient ten	nperature	-10°C +60°C				
Continuous	duty	ED 100% (see note "A" overleaf)				
Electric conr	nection	DIN 46340 - 3 poles plug connector				
Protection d	egree	IP 65 (EN 60529) with plug connector	IP 67 (EN 60529) with plug connector			
Voltages	DC	12-24V (+10%)				

Port Orifice size ISO 228 (mm)	Inlet differential pressure (bar)		Series and type		Power absorption					
	Min	May	Valve	Coil	AC (VA)		DC	Sealings	Notes	Weight (kg
	(mm)	IVIIII	Max	vaive	Coil	Inrush	Holding	(VV)		
G 1/8 1,6	1.6	1,6 0 6	L194D01	ZB10A ZB12A	-	-	5,5	EPDM	-	0,160
	1,6		L194V01					FPM		


- Sealings: EPDM = Ethylene-propylene elastomer. FPM = Fluoro-carbon elastomer
- · Contact us for different pressure ratings and different proportionality features (flow rate/electric signal)
- ZB12A coils fitted with sealing gasket underneath and on the upper part.



REFERENCE CURVE WITH INLET PRESSURE P1 = 6bar (dehumidified and non-lubricated air and valve in vertical position)

Reference coil 24V DC

(See note "A")



## Installation

• Solenoid valve can be mounted in any position; vertical with coil upwards preferred.

## NOTE "A"

It is necessary to keep the current circulating in the coil constant, so as to maintain the solenoid valve in any pre-determined position. In case the solenoid valve is energised by voltage variation, it has to be considered that the resistance of winding increases because of the continued energizing and consequently the power decreases. Therefore, it is necessary to compensate such power decrease by increasing the voltage to re-establish the initial current value.